

ISO9001 **C** QACE202401069 NFC-500IL FIRE REMOTE INDICATOR

INSTILLATION MANUAL


FEAURES	TECHNICAL DATA	
√ Highlight LED	MODEL NUMBER	NFC-500IL
√ Wall and Ceiling Mounting	Max. Power Source	24V DC
$\sqrt{\text{Easy installation}}$ and connection	Alarm Current @24V DC	12mA
√ Low current consumption	Standby Current	0mA
√ High intensity LED for quick	Relative Humidity	95%
identification.	Ambient Temperature	-10° C ~ +55°C
	Indicator	Red LED
	Material	ABS (Fire Proof Plastic)
	Color	White Surface \ Red Lamp
	Weight	37gm.

MECHANICALS

- **Dimensions**: 120mmx 70mmx15mm

- Mount Style: Surface mount with screw (2pcs)

- Led Dia. : 5mm



INSTALLATION AND PRECAUTIONS

Before Installation

Ensure that the power is turned off and the fire remote indicator must be installed in compliance with the control panel installation manual.

Device Installation

- Mount the indicator on a flat surface using provided screws
- connect the positive and negative leads to the corresponding terminals on the fire alarm control panel
- Secure the connections and restore power to the system
- test the indicator for proper operation.
- Once all testing has been carried out on the cabling and continuity & insulation
- Has been proven, NFC-500IL can be connected.

PCB NEVERFIRE MADE IN EGYPT

TO Smoke/Heat Detector

TECHNICAL SUPPORT AND MAINTENANCE INSTRUCTIONS

- Due to the complexity and inherent importance of a life risk type system, Training on the equipment is essential and commissioning should be carried out by competent persons.
- Ensure that the detector connected to the Remote Indicator is adjusted into the fire state to ensure that the LED operates successfully.

For Maintenance

you should keep your device as the following:

- Regular inspect the indicator for dust and debris
- Clean with a dry cloth as needed
 - Check connections periodically to ensure reliability

©2025 ASSS com., The company reserves the right to change the specifications of the products at any time and without prior notice. All information in this documents is given in good faith but ASSS com. Cannot be held Responsible for any imissions or errors. Printed in Egypt.

AL ALAMYIA FOR SAFETY & SECURITY SYSTEMS COM. (ASSS)

Factory: 16G, south industrial Zone, 10th of Ramadan City, Sharkyia, Egypt. Administration: No.6, 163 St, Behind the military hospital, El Maadi, Cairo, Egypt.

TEL.: +2 02 25249113 **FAX.**: +2 02 25281778 MOBILE: +2 0112927726

E-Mail: info@asss-eq.com WWW.ASSS-EG.COM ASSS FACTORY is the first manufacture for fire alarm system in Africa & middle east.

The com. established since 2011 located in cairo governorate while the factory located in Sharkyia governorate.